



---

*Before installing this product, check the contents of the kit. If anything is missing, please contact an Öhlins dealer.*

---

#### **Kit Contents**

	Part No	Pcs
Shock absorber	HO 122	1
Memo notes sticker	01180-01	1
Tool preload adjuster	03199-03	1
Öhlins sticker	00192-01	2
Owners manual	07241-02	1

#### **👁 Note!**

*Please note that this image is a general representation of the product and may differ slightly from your product.*

---

#### **👁 Note!**

*Please note that during storage and transportation, especially at high ambient temperature, some of the oil and grease used for assembling may leak and stain the packaging. This is in no way detrimental to the product, wipe off the excessive oil/grease with a cloth.*

---

#### **⚠ Warning!**

*Before installing this product, read the Öhlins Owner's Manual. The shock absorber/front fork/steering damper is an important part of your vehicle and will affect the stability.*

---

## **Shock absorber for Honda CBR 250 R**

# **HO 122**

## **Mounting Instructions**



# MOUNTING INSTRUCTIONS

## **Warning!**

*It is advisable to have an Öhlins dealer install the shock absorber.*

---

## **Warning!**

*If working on a raised vehicle, ensure it is securely supported so that it will not tip.*

---

## **Note!**

*Before mounting this product clean the vehicle thoroughly.*

---

## **Note!**

*When working on this product, always see the Vehicle Service Manual for vehicle specific procedures and important data.*

---

**1**

Put the motorcycle on a workstand so that the rear wheel barely touches the ground.

**2**

Remove the original shock absorber, See your vehicle service manual.

**3**

Install the öhlins shock absorber in reversed order in same position as your original shock absorber.

## **Note!**

*Lower the vehicle so that the suspension is slightly compressed before tightening the screws.*

---

**3**

Make sure that all removed parts are reinstalled in the same way as they were before installation of the Öhlins shock absorber.

## **Caution!**

*Ensure that all screws are tightened to the correct torque and that nothing fouls or restricts movement of the shock absorber/front fork/steering damper when the suspension is fully compressed or extended.*

---

# MOUNTING INSTRUCTIONS

# ADJUSTMENTS

## **Warning!**

*Before riding, always make sure that the basic settings made by Öhlins are according to recommended Set-up Data. Read about adjustments and setting up in the Öhlins Owner's Manual before you make any adjustments. Contact an Öhlins dealer if you have any questions about setting up.*

Spring Preload Adjuster



# SET-UP DATA

## **Recommended set-up**

Spring Preload..... 8mm

## **Spring**

Part No. .... 00281-17

Free spring length..... 180mm

## **Shock absorber data**

Length..... 297mm

Stroke ..... 54mm

 *Öhlins products are subject to continuous improvement and development, therefore, although these instructions include the most up-to-date information available at the time of printing, minor updates may occur.*

*To find the latest information contact an Öhlins distributor. Please contact Öhlins if you have any questions regarding the contents in this document.*

Part no. MI\_HO122\_1  
Issued 2014-03-10

© Öhlins Racing AB. All rights reserved. Any reprinting or unauthorized use without the written permission of Öhlins Racing AB is prohibited.

Öhlins Racing AB  
Box 722  
S-194 27 Upplands Väsby, Sweden  
Phone +46 8 590 025 00  
fax +46 8 590 025 80



[www.ohlins.com](http://www.ohlins.com)