


ADJUSTMENTS

⚠ Warning!

Before riding, always make sure that the basic settings made by Öhlins are according to recommended Set-up Data. Read about adjustments and setting up in the Öhlins Owner's Manual before you make any adjustments. Contact an Öhlins dealer if you have any questions about setting up.



SET-UP DATA

Recommended set-up

Rebound 18clicks
Compression
 high speed 30clicks
 low speed..... 18clicks
Spring Preload..... 13mm

Spring


Part No. 01092-34
Free spring length..... 170mm

Shock absorber data

Length..... 326,5mm
Stroke 68

Sag and Ride Height

F1-F2 = 22mm (Öhlins front fork springs)
F1-F3 = 31mm
R1-R2 = 13mm
R1-R3 = 45mm



👁 Note!

Please note that this image is a general representation of the product and may differ slightly from your product.

👁 Note!

Please note that during storage and transportation, especially at high ambient temperature, some of the oil and grease used for assembling may leak and stain the packaging. This is in no way detrimental to the product, wipe off the excessive oil/grease with a cloth.

Before installing this product, check the contents of the kit. If anything is missing, please contact an Öhlins dealer.

Kit Contents

	Part No	Pcs
Shock absorber	SU120	1
Öhlins Sticker	00192-01	2
C-spanner	00710-02	1
Sticker Memo Notes	01180-01	1
Owner's Manual	07241-02	1

⚠ Warning!

Before installing this product, read the Öhlins Owner's Manual. The shock absorber/front fork/steering damper is an important part of your vehicle and will affect the stability.

👁 Öhlins products are subject to continuous improvement and development, therefore, although these instructions include the most up-to-date information available at the time of printing, minor updates may occur.

To find the latest information contact an Öhlins distributor. Please contact Öhlins if you have any questions regarding the contents in this document.

Part no. MI_SU120_2
Issued 2011-11-01



Shock Absorber for Suzuki GSR 750

SU 120

Mounting Instructions

© Öhlins Racing AB. All rights reserved. Any reprinting or unauthorized use without the written permission of Öhlins Racing AB is prohibited.

Öhlins Racing AB
Box 722
S-194 27 Upplands Väsby, Sweden
Phone +46 8 590 025 00
fax +46 8 590 025 80



www.ohlins.com



MOUNTING INSTRUCTIONS

⚠ Warning!

It is advisable to have an Öhlins dealer install the shock absorber/front fork/steering damper.

⚠ Warning!


If working on a raised vehicle, ensure it is securely supported so that it will not tip.

👁 Note!

Before mounting this product clean the vehicle thoroughly.

👁 Note!

When working on this product, always see the Vehicle Service Manual for vehicle specific procedures and important data.



1

Put the motorcycle on a workstand so that the rear wheel barely touches the ground.

2

Remove the seat and side panels on both sides.

3

Loosen the upper and lower attachments of the original shock absorber.

4

Raise the rear wheel and remove the original shock absorber.

5

Install the Öhlins shock absorber in reverse order.

6

Ensure that all removed parts are reinstalled in the same position as they were before the installation of the Öhlins suspension.

👁 Note!

Lower the vehicle so that the suspension is slightly compressed before tightening the screws.

👤 Caution!

Ensure that all screws are tightened to the correct torque and that nothing fouls or restricts movement of the shock absorber/front fork/steering damper when the suspension is fully compressed or extended.

MOUNTING INSTRUCTIONS